



# POSIM PROCEDURE SHEET

## Fitting Scanstrip to a Retail Shelf

1. Make sure shelf edge is clean, dry and free of any adhesives or greasy substances.
2. Wipe shelf edges with white spirit, commonly known as dry cleaning fluid on a DRY cloth. (Damp or wet cloths will dilute the white spirit).
3. Allow 10 minutes for the white spirit to dry.
4. Measure Scanstrip against the shelf edge before applying as some trimming may be required. A sharp Stanley or craft knife will do the job nicely.
5. Peel backing tape from a section of the back of the Scanstrip as you begin adhering it to the edge of the shelf. Continue peeling tape off as you advance along the shelf. Allow the bottom of the Scanstrip to overhang the bottom of the shelf. This will make ticket insertion easier and will also extend the life of the Scanstrip.
6. Once Scanstrip is in position, smooth along the entire length with a soft cloth and apply firm pressure.
7. Allow 24hours for the adhesive to "cure" before inserting price tickets.
8. To insert price tickets, place medium thumb pressure against the overhanging portion at the bottom edge of the Scanstrip. This will make the stripping open up for easy ticket insertion.

**Scanstrip should never be prised open at the top edge to insert tickets.**

**Note:**

Scanstrip for damp or refrigerated areas should be applied when fridges are turned off and surfaces are dry. Once adhesive has "cured" dampness should not be a problem. If fridges cannot be turned off to apply Scanstrip, use alternative Hangscan, Fridgescan or Wire Shelf Scanstrip as these profiles do not have adhesive.